



Bracket Mounting Instructions

For EcoLux Air Dispenser wall mounted holders

Adhesive Mounting

- Select an appropriate location where bracket(s) can be secured by referring to Additional Notes.
- Utilize, if required, the enclosed template to level and mount the brackets for single, double, or triple bottle use.
- Wipe the surface of the wall with rubbing alcohol and allow to completely dry.
- Remove the strip from one side only of the double-sided tape and apply to the back of the bracket ensuring the tape fits without extending past the edges.
- Apply adhesive gel to the back side on all areas of the back side of the bracket that are not taped.
- Remove the remaining non-adhesive backing from the tape and firmly press the bracket to the wall.
- Wipe all adhesive pressed out from under the bracket while holding the bracket in place.
- Allow a 24-hour waiting period prior to loading bottles to ensure that the adhesive has set.
- Prior to mounting dispenser bottles to brackets, spin the top of pump several turns until pump pops up, indicating it is ready for use.

Drill Mounting

- Select an appropriate location where bracket(s) can be secured by referring to Additional Notes.
- The enclosed template can be utilized to level and mount the brackets for single, double, or triple bottle use.
- Utilize the holes on the bracket to select position for holes, drill and set plastic anchors into the wall.
- Cut anchor tip if necessary to allow complete, flush insertion into wall.
- Screw the dispenser bracket onto the wall.
- Prior to mounting dispenser bottles to brackets, spin the top of pump several turns until pump pops up, indicating it is ready for use.

Additional Notes

- Although holders are suitable for most surfaces, they are not guaranteed for all. Please ensure that the dispenser is suitable for the desired surface prior to installation.
- Ensure that all units are installed at a uniform height.
- Ensure that showerheads do not obstruct installation locations.
- Place dispenser near the corner to reduce hazard.
- Bracket Mounting Template measured for finished, installed dispenser bottles to be $\frac{3}{4}$ " apart.
- For best results, clean bottle and wall with mild soapy water and microfiber cloths. In hard water areas, clean with vinegar to remove limescale. Harsh chemicals or abrasive cleaners should not be used.
- When loading the bottle, slide down and push against the bracket to ensure the bottle clicks into the locked position. When removing the bottle, use the included white key tool to unlock the bottle from the bottom of the bracket.