



Bracket Mounting Instructions

For single, double and triple wall mounted holders

Adhesive Mounting

1. Select an appropriate location where bracket(s) can be secured.
2. Ensure that placement will allow for suitable height above and below holder to access for refilling bottle.
3. Use bracket as a template with a level to mark the wall.
4. Wipe the surface and the wall with rubbing alcohol.
5. Make sure the installation surface is clean and dry.
6. Place the double stick tape centered on the back of the bracket.
7. Apply silicone gel in a wavy motion around the tape on the back side of the bracket. For ease of installation, we recommend using a larger tube of clear waterproof construction grade multi-surface adhesive (Ex. Loctite Power Grab Ultimate Crystal Clear Construction Adhesive).
8. Remove the non-adhesive backing of the tape and carefully attach the bracket to the wall.

Note: Although holders are suitable for most surfaces, it is not guaranteed for all.
Please ensure that the dispenser is suitable for the desired surface prior to installation.

Allow a 24 hour waiting period prior to loading bottles to ensure that the adhesive has set.

Shower Locations

The recommended minimum height from floor to bottom of the holder is 40 inches.
Place dispenser near the corner to reduce hazard.

Installing and Re-Filling Bottles

Installing Bottles

1. Load the bottles. Fit the bottom of bottles first for an easier installation
2. Secure bottles with included tamper-resistant locking clamps

Re-filling Bottles

Use bottle release key to press upward in designated holes at the bottom of the unit while gently pulling the bottle out. Do not turn or twist the unlocking key to avoid its damage.

Cleaning

For best results, clean with mild soapy water and microfiber cloths. In hard water areas, clean with vinegar to remove limescale. Harsh chemicals or abrasive cleaners should not be used.

Note: Dispensers require regular interior cleaning and sanitizing.



Bracket Mounting Instructions

For single, double and triple wall mounted holders

Drill Mounting

1. Select an appropriate location where bracket(s) can be secured.
2. Ensure that placement will allow for suitable height above and below holder to access for refilling bottle.
3. Use bracket as a template with a level to mark the wall.
4. Drill into the wall using an appropriate drill bit and fit plug.
5. Attach the holder to a wall.

Note: Although holders are suitable for most surfaces, they are not guaranteed for all. Please ensure that the dispenser is suitable for the desired surface prior to installation.

Shower Locations

The recommended minimum height from floor to bottom of the holder is 40 inches.
Place dispenser near the corner to reduce hazard.

Installing and Re-Filling Bottles

Installing Bottles

1. Load the bottles. Fit the bottom of bottles first for an easier installation
2. Secure bottles with included tamper-resistant locking clamps

Re-filling Bottles

Use bottle release key to press upward in designated holes at the bottom of the unit while gently pulling the bottle out.

Do not turn or twist the unlocking key to avoid its damage.

Cleaning

For best results, clean with mild soapy water and microfiber cloths. In hard water areas, clean with vinegar to remove limescale. Harsh chemicals or abrasive cleaners should not be used.

Note: Dispensers require regular interior cleaning and sanitizing.